
Important Operating Instructions and Warranty Information On Your New Electronic AMSEC Safe

MODELS:
LP5924WE, LP6032WE, LP6036WE

Read Contents Carefully For Trouble-Free Operation of Your Safe

Dear Valued Customer:

Congratulations on your purchase of the finest safe from American Security Products, Co.

You've taken an important step in organizing and protecting your most valued possessions. Every AMSEC safe is professionally hand-crafted and designed to provide a lifetime of trouble-free performance.

AMSEC offers the industry's finest warranty backed by a nationwide network of highly skilled authorized dealers, providing prompt, courteous, and professional service. We suggest that you read the Limited Warranty thoroughly, and invite you to contact your authorized AMSEC dealer or AMSEC's Service Department if you have any questions.

Please also take the time to read and familiarize yourself with the proper operating procedures of your new safe presented on the following pages.

Again, Congratulations and Thank You for selecting AMSEC!

If you like us to send AMSEC Safe information to a friend or have any questions concerning our complete line of security products, please send your request to:



**AMERICAN SECURITY
PRODUCTS COMPANY**
11925 Pacific Avenue
Fontana, California 92337
Visit us on the web at:
www.amsecusa.com

OPERATING INSTRUCTIONS FOR THE ESL10XL ELECTRONIC SAFE LOCK

Your AMSEC ESL10XL Electronic Safe Lock has a Factory Combination of:

C-1-2-3-4-5-6-#

To open the lock simply press the "C" key to clear and wake up the electronics. Now press the keys of the combination one at a time and finish with the "#" key. If the combination keyed is correct, the lock will cycle open for three (3) seconds. During this 3-second period, turn the handle of the safe to the unlocked position and pull the door open.

Here are a few things to remember:

- a. With each keystroke the red lamp on the keypad will flash and a chirp will be heard.
- b. If four (4) incorrect combinations are entered, the lock will go into a "Penalty Lockout" for 15 minutes to prevent trial and error manipulation attempts at opening the lock. The red lamp will flash once every 5 seconds during the penalty period. If you press any key during the lockout period, the red lamp will flash with a chirp 8 times rapidly to indicate the lockout condition.
- c. Before keying the combination, be sure that the handle of the safe is in fully locked position to allow the lock to open freely.
- d. If the lock fails to open or acts strange, replace the batteries with good quality fresh **ALKALINE** 9 volt batteries. To replace the batteries, simply turn the keypad housing counter-clockwise to the stop and pull it away from the base. Un-snap the old batteries and clip on the new one. Position them in the pocket at the bottom of the housing and replace it watching that the wires are not pinched. You should replace the batteries once a year to prevent corrosion damage from leak.
- e. During the input sequence, if you make a mistake, you can press "C" to clear the previous input and start over again.
- f. The ESL10XL uses a *fixed length six (6) digit combination*.
- g. Use only your fingers to key the combination. Sharp objects will result in damage which is not covered by the warranty.
- h. If at any time during opening or combination changing the unit is left without input for ten (10) seconds, it returns to a resting condition. If this occurs during a combination change, the Old Combination is retained.
- i. At any time during opening or combination changing the unit will register the first 5 digits of the combination into the "buffer" that receives input. The 6th digit will be the last numeric key pressed. For example, if you press **C-1-2-3-4-5-7-4-5-2-7-6-#** the program recognizes only the C-1-2-3-4-5-6-# input. The last numeric key pressed continues to replace the one prior until the "#" key is pressed to indicate completion. This is a security feature that allows you to baffle an on-looker that may be trying to memorize your combination.

COMBINATION CHANGING INSTRUCTIONS FOR THE ESL10XL ELECTRONIC SAFE LOCK

You may change your combination any time you like and as many times as you like. Once your safe is installed, you must change the combination to a number sequence other than the Factory Combination of 1-2-3-4-5-6 to insure security.

CAUTION: Combination changes should always be done with the door LOCKED OPEN.

The input of a new combination is done by keying a "Change Key" code, followed by the Old Combination to validate a change and then followed by entering the New Combination twice to avoid a keying error. To change the combination do the following:

- a. Press the keys "C" and then "#." This is the "Change Key" that activates the change routine. The unit responds with a short warbling tone (called the "good combo tone") and the red lamp strobes with the tone.
- b. Now key in the Old 6-digit combination. The "C" key may be used to clear an error in keying at any time. Finish the input with a "#" key.
 1. If the old combination keyed matches the existing combination in permanent memory, another short good combo tone is sounded. Proceed to "c."
 2. If the combination keyed is incorrect, the unit responds with 4 short beeps (called the "bad combo tone") and returns to rest. The combination change routine is aborted and the old combination is retained. This also causes a count up for Penalty Lockout.
- c. Now key the first pass with the New 6-digit combination followed by a "#" key. Again, the "C" key may be used to clear an error in keying at any time.
 1. If the combination input is 6 digits in length, another short good combo tone is sounded. Proceed to "d."
 2. If the combination keyed is not 6 digits long, the unit responds with 4 short beeps (bad combo tone) and returns to rest. The combination change routine is aborted and the old combination is retained.
- d. Now key the second (verify) pass with the New 6 digit combination followed by a "#" key. As before, the "C" key may be used to clear an error in keying at any time.
 1. If the combination input matched the first pass, a long good combo tone is sounded. The New Combination replaces the Old Combination in permanent memory and the unit returns to a resting condition. Proceed to "e."
 2. If the combination keyed does not match the first pass, the unit responds with the bad combo tone and returns to rest. The combination change routine is aborted and the Old Combination is retained.
- e. Test your New Combination several times prior to closing and locking the safe.

Limited Product Warranty

LIMITED WARRANTY—SECURITY SAFES & ELECTRONIC PRODUCTS

Product Category

Duration of Warranty

(Beginning from date of first consumer purchase / Proof of purchase necessary)

All Safes and related components 1 Year Parts & Labor

Electronic Locks and related components 1 Year Parts & Labor

What is covered and what is not covered:

This warranty covers all defects in materials or workmanship in this product, but DOES NOT COVER:

- (1) Damage, deterioration or malfunction resulting from:
 - a. Accident, negligence, misuse, abuse, improper installation, failure to perform normal maintenance or operation to follow instructions labeled on or provided in the safe.
 - b. Any damage occurred from shipment. (Claims must be presented to the carrier)
 - c. Repair or attempted repair by anyone other than a pre-authorized AMSEC service dealer.
- (2) Any unit which has been altered or on which the serial number has been defaced, modified or removed.
- (3) Normal wear, battery replacement, any periodic maintenance or where combination lock has been changed without factory authorization.

Who may enforce the warranty:

This warranty is only enforceable by the original purchaser.

What we will pay for and what you must pay for:

AMSEC will repair or replace units covered by this warranty, without charge to the consumer for labor and materials. **YOU ARE RESPONSIBLE FOR ANY INSTALLATION OR REMOVAL CHARGES AND FOR ANY SHIPPING CHARGES.** State sales tax does not apply to warranty service work and will not be honored. If safe components must be shipped for warranty service, AMSEC will pay the shipping charges to any destination within the USA if the repairs are covered by the warranty. Defective parts must be returned (not repaired unless instructed) to AMSEC. If parts are not returned, the warranty invoice will be denied.

How you can get warranty service:

- (1) If your AMSEC safe requires service, contact your local authorized AMSEC dealer and the dealer will advise you of the procedures to be followed. If this is not practical, contact the AMSEC Service Department at the address on front cover or call 951-685-9680, ex. #1036.
- (2) All warranty service must have prior authorization, accompanied by proof of purchase as evidence of warranty coverage. A warranty authorization number must be obtained from AMSEC before any service work is performed. The serial number, description of product and description of problem must be supplied to AMSEC to determine warranty status before an authorization number will be assigned. Issuance of the authorization number recognizes only the existence of the problem and does not constitute an admission of liability by AMSEC. Only approved service representatives will be authorized to perform warranty service. Any service performed prior to issuance of a warranty authorization number will be subject to denial.

Limitation of Implied Warranties:

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty.

Exclusions of Damages:

AMSEC's liability for any defective products is limited to repair or replacement of the product, at our option.

AMSEC shall not be liable for damages based upon inconvenience, loss of use, damage or loss of contents, or any other damages whether incidental, consequential or otherwise.

CAUTION FIRE SAFE CONTENT STORAGE

A fire safe contains insulation material, which may cause humidity to be present when closed extended periods of time. It is recommended that the safe is opened on a regular basis and interior allowed to air out. It is also recommended that documents sensitive to moisture be kept in a sealed container, I.E Ziplock® or Tupperware®.

MAINTENANCE

Standard Textured finish: Your safe is provided with a durable paint that may be easily cleaned with a mild detergent and a soft cloth. **Do Not** use abrasive scouring pads or any chemical fluids, which may react and damage the finish.

Door Operating Mechanism: The handle of the safe moves mechanical parts inside the door. After a period of use, if difficulty is experienced in operation, please contact a qualified locksmith for service.

Door Hinges: If the door becomes hard to open or emits noise, the hinges may need lubrication. Please contact a qualified locksmith for service.

Caution: AMSEC assumes no liability for finish damage due to the incorrect use of caustic lubricants.

DAMAGE CLAIMS

Freight Damage: All safes are carefully packed for shipment. The manufacturer's liability ceases when the transportation carrier accepts the shipment in good condition. The carrier's liability ceases when you sign for the merchandise. **INSPECT YOUR SHIPMENT BEFORE SIGNING THE DELIVERY RECEIPT.** Although unlikely, if damage occurs you have the option of refusing the shipment or negotiating a settlement with the carrier. To negotiate a settlement follow these steps:

1. Note the extent of the damage on the freight bill and sign your name.
2. Save all cartons and packaging materials.
3. Call the freight carrier immediately and request a damage inspection claim.

All Claims:

1. Contact your dealer immediately.
2. Claims must be filed within 15 days.
3. Claims must be accompanied by proof of purchase receipt and photographs.
4. In the event of replacement, the safe must be returned to the dealer/factory in the original packaging.

